



Parts List

Item	Qty
Chaincase Protector	1
M6x 16mm long bolt	4
M6 flanged lock nut	4

Chaincase Protector Installation Instructions

1. Remove the footwell grill inside the right footwell, just as you would if you were changing the oil.
2. (Viper Only) Remove the rivet shown below and drill the hole out with a 15/64" drill bit. This hole serves as one of the mounting holes. Fit up the protector and trim the plastic belly pan away with a utility knife so protector can sit flush on the frame



3. (Viper Only) Once plastic is trimmed, attach protector at the hole drilled in step 2. Ensure the inside protector edge is parallel to the inside of tunnel. Drill the second front mounting hole and install a mounting bolt and nut. Nuts go on the inside so bottom is snag free.
4. (Sidewinder Only) Hold the protector in place ensuring the front clears the plastic and sits flush on frame. Also ensure inside edge of protector is parallel to tunnel. Drill (1) of the front mounting holes and secure protector with bolt and nut. Double check to ensure protector is parallel and drill the second front mounting hole. Install the second mounting bolt. Nuts go on inside.
5. Once the front is secured proceed to drill the 2 rear mounting holes. The rear of the protector may not sit flush on the frame but once the bolts are installed it will draw the protector tight. Install the 2 rear mounting bolts.



6. After all fasteners are tightened re install the footwell grill.