

3. Installation

FX NYTRO RTX, XTX Models

- a) Remove the two push nuts located on the tunnel. Remove the reflector located on the side of the tunnel (see Fig. 5).
- b) Drill out the rivet with a 3/16" DIA drill bit as illustrated (see Fig. 6).
- c) Slide the upper part of the gas caddy (#1) under the plastic support of the seat and fasten onto the tunnel using (2) M8x20mm Allen socket machine screws (#11), (2) 5/16" DIA flat washers (#16), and (2) M8 nylock nuts (#15) (finger tighten only at this time) (see Fig. 7).
- d) Fasten the lower part of the gas caddy (#1) onto the tunnel side using (2) M5x25mm Allen socket machine screws (#10), (2) grommets (#19), and (2) M5 nylock nuts (#14). Tighten all machine screws and nuts (see Fig. 7).
- e) Position the gas tank (#5) on the gas caddy (#1) and secure with strap (see Fig. 8).

