

Using tool (p/n 0744-067) pull the brake caliper/bearing assembly off the drive shaft.

