

Top Gear	Bottom Gear	Gear Ratio	Chain Length
18	43	2.39	68
18	42	2.33	68
18	41	2.28	68
18	40	2.22	68
18	39	2.17	66
18	38	2.11	66
19	43	2.26	70
19	42	2.21	68
19	41	2.16	68
19	40	2.11	68
19	39	2.05	68
19	38	2.00	66
20	43	2.15	70
20	42	2.10	70
20	41	2.05	68
20	40	2.00	68
20	39	1.95	68
20	38	1.90	68
21	43	2.05	70
21	42	2.00	70
21	41	1.95	70
21	40	1.90	68
21	39	1.86	68
21	38	1.81	68
22	43	1.95	70
22	42	1.91	70
22	41	1.86	70
22	40	1.82	70
22	39	1.77	68
22	38	1.73	68
23	43	1.87	72
23	42	1.83	70
23	41	1.78	70
23	40	1.74	70
23	39	1.70	70
23	38	1.65	68
24	43	1.79	72
24	42	1.75	72
24	41	1.71	70
24	40	1.67	70
24	39	1.63	70
24	38	1.58	70
25	43	1.72	72
25	42	1.68	72
25	41	1.64	72
25	40	1.60	70
25	39	1.56	70
25	38	1.52	70

#### Top Gear Cost

18 = **\$35**  
 19 = **\$35**  
 20 = **\$35**  
 21 = **\$35**  
 22 = **\$35**  
 23 = **\$35**  
 24 = **\$35**  
 25 = **\$35**  
 26 = **\$35**

#### Standard Bottom Gear Cost

38 = **\$50**  
 39 = **\$50**  
 40 = **\$50**  
 41 = **\$50**  
 42 = **\$50**  
 43 = **\$50**

#### Reverse Bottom Gear Cost

38 = **\$127**  
 39 = **\$127**  
 40 = **\$127**  
 42 = **\$150**

#### Chain Cost

68 link = **\$107**  
 70 link = **\$107**

26	43	1.65	72
26	42	1.62	72
26	41	1.58	72
26	40	1.54	72
26	39	1.50	70
26	38	1.46	70

Top gears 18 to 26 will work on all models when used with correct chain length.

Bottom gears 38, 39, 40, and 42 available for reverse.

Bottom gears 38 to 43 will work on **non-reverse** models when used with correct chain length.